



TOFFING COLUMN

The topping column removes light ends such as dissolved gases and low-boiling impurities from the crude methanol stream. The purified methanol is fed to the refining column, while overhead vapors are condensed and partially purged.