

Emulsion Polymerization

Description

Emulsion polymerization involves the formation of synthetic latexes and resins by the polymerization of a monomer-in-water emulsion. The resulting polymer dispersion in water may be used in this form, such as for water-based paint, adhesives and the preparation of foam rubber. For other applications the water may be removed by spray drying or other means to produce a free-flowing powder or coagulated cake.

The following materials are frequently polymerized in the emulsion state:

1. synthetic rubber latexes - butadiene-styrene, acrylonitrile-butadiene, polybutadiene, polychloroprene and polyisoprene;
2. coating latex - polyacrylates, polyvinyl acetate, polyvinyl chloride and polyethylene copolymers;
3. plastisol resins (a resin mixed with a plasticizer to make a paste) polyvinyl chloride;
4. specialty latexes - polyethylene and polytetrafluoroethylene.

The ingredients used in an emulsion polymerization are listed in the following generalized recipe (Martens, 1964):

Component	%-Wet Basis
Monomers	30 - 50
Surface-active agents	1 - 3
Protective colloid	0 - 3
Initiator	1 - 3
Modifier	0 - 1
Buffer	0 - 1
Water	50 - 70

In some cases the monomer emulsion is seeded with polymer articles. "The purpose of seeded emulsion polymerization is to avoid the uncertainties of the particle initiation stage, obtain better batch-to-batch reproducibility, and give a stable latex of the desired particle size" (Bassett, 1981, p. 199). The reasons for polymerizing in water include: more rapid polymerization than bulk polymerization at the same temperature with a greater average molecular weight; good heat transfer in water with better control of heat of polymerization; all of the monomer is consumed in the polymerization and the resulting latex can be used directly in coating applications; and the aqueous phase lowers the overall viscosity of the emulsion.

Polymerization Mechanism

The monomer emulsion is made up of water-immiscible monomer droplets stabilized by surfactant molecules, empty micelles (colloidal surfactant vesicles) and monomer-swollen micelles. The monomer droplets can range in size from less than one micrometer to ten micrometers. The size of micelles is about 10 to 15 nanometers. During the reaction, the monomer molecules diffuse from the droplet reservoirs to the micelles where polymerization takes place. The polymer chains grow in the micelles. As polymerization proceeds, the monomer droplets decrease in size and eventually disappear. When the polymer particles become large, the surfactant molecules in the micelles suspend the polymer particles. The final polymer particles grow to a size range of a few tenths of a micrometer up to one micrometer. The physical character of the final polymer depends on the temperature of reaction, the formulation and the manipulation of the reaction conditions, such as when and how much of the ingredients are added to the reactor.

Process

The homogenizer is used in emulsion polymerization to emulsify the monomer into the premix to the reactor. Of all the emulsion monomers, vinyl chloride polymerization is the one that most commonly uses homogenizers to prepare the mix.

In a typical process the ingredients to make the polymer are added in the appropriate sequence to an evacuated, agitated, pressurized tank (pressurized with nitrogen gas). After mixing the ingredients and adjusting the temperature of the mix, the emulsion is homogenized to produce the desired monomer droplet size. The homogenizing pressure may be in the range of 1000 to 5000 psi, depending on the monomer and the required droplet size of the monomer reservoir. This monomer droplet size can affect the physical character of the final latex particles. From the homogenizer the emulsion goes to the reactor, where polymerization occurs at a controlled temperature, until the desired conversion is achieved. After completion of the reaction, the latex is cooled and removed from the reactor.

When processing a monomer, such as vinyl chloride, certain safety precautions must be observed. Vinyl chloride monomer is a clear, colorless liquid with a boiling point of -13.3°C ($+8\text{ F}$). It is flammable in air, has a density greater than air and is listed as a known carcinogen. Therefore, special homogenizer design requirements are necessary for processing vinyl chloride monomer.

References

- D. T. Barnette and F. J. Schork, "Continuous Miniemulsion Polymerization", *Chemical Engineering Progress* (June 1987: 25-30).
- D. R. Bassett and A. E. Hamielec, eds., *Emulsion Polymers and Emulsion Polymerization*, ACS Symposium Series No. 165 (Washington, D. C.: American Chemical Society, 1981).
- C. Bush and B. Mikofalvy, U. S. Patent 4,186,259 (1980).
- D. M. Considine, ed., *Chemical and Process Technology Encyclopedia* (New York: McGraw-Hill, 1974).
- P. J. Flory, *Principles of Polymer Chemistry* (London: Cornell University Press, 1971).
- C. R. Martens, *Emulsion and Water-Soluble Paints and Coatings* (New York: Reinhold Publishing, 1964).



611 Sugar Creek Road, Delavan, WI 53115

P: (262) 728-1900 or (800) 252-5200, F: (262) 728-4904 or (800) 252-5012, E: wcb@spx.com

SPX reserves the right to incorporate our latest design and material changes without notice or obligation. Design features, materials of construction and dimensional data, as described in this bulletin, are provided for your information only and should not be relied upon unless confirmed in writing. Please contact your local sales representative for product availability in your region. For more information visit www.spx.com. The green ">" is a trademark of SPX Corporation, Inc.

ISSUED: 02/2009 3050-01-07-2008-US COPYRIGHT © 2008, 2012 SPX Corporation