

CYLINDERS

Hytec's wide variety of reliable, versatile cylinder styles makes choosing the one that's right for your job easier than ever before.

Threaded Body Cylinders

These cylinders are designed specifically to get the highest clamping force in the smallest area. Their compact size allows them to be mounted very close together or close to other components on the fixture.

Threaded body cylinders are single-acting, spring-return, and because of their versatility, can be outfitted for a wide variety of applications. Available in either Unified National Coarse or Fine threads, they're ideal for manifold mounting, but can also be used with external plumbing connections when fitted with a feeder cap. Mounting brackets and jam nuts are also available. The threaded pistons accept optional Hytec pointed or crowned threaded inserts, flat faced toggle pads, or custom designed attachments.

Cylindrical Body Cylinders

Compared to other mounting methods, these cylinders take up much less fixture space thanks to the snap ring method of securing them to the fixture.

They are double-acting only and do not contain return springs, making them perfect for applications where rapid, positive return is essential, or where both pushing and pulling forces are necessary.

Cylinder control can be simplified in certain applications by supplying one side of the cylinder with a constant air pressure source to control the return force. The other port can then be pressurized or released hydraulically as if it were a single-acting component.

New threaded piston rods make it easy to use these cylinders in a variety of applications because they can be used with Hytec threaded inserts or custom designed attachments.

Mount the cylinders by simply inserting them into a drilled hole and securing with snap rings (included). For conventionally mounted applications, the optional feeder caps have both side and end ports for plumbing variations. Or, use the manifold mounting option and mount directly on a flat surface. Optional mounting brackets are also

available.

Center Hole Cylinders

One of the most common uses for this cylinder is to convert a strap clamp from manual to power operation. The nut used to create the clamping force is replaced by the center-hole cylinder, threaded right onto the stud and secured with the same nut. When the cylinder is extended, the studs tension creates clamping force just as when the nut was torqued.

Center-hole cylinders can be used as single or double-acting workholding devices. The



piston return spring cavity is sealed, ported, and plugged with a breather, making it ready for use in single-acting operations. Remove the breather and connect a hydraulic or air line, and the cylinder is converted for double-acting operation.

Mounting can be done several ways: use the thru-holes for top mounting, use the tapped holes in the bottom for mounting from underneath, or secure with a single stud or rod through the center. The pistons are threaded to accept the optional crowned threaded inserts, used when the cylinder contacts the work directly.

Piston force is equal whether it's being extended or retracted, so these cylinders are ideal for pushing and pulling applications and will accept any user-designed pushing or pulling attachment. A double-acting cylinder can handle heavy attachments when a single-acting one won't.

Low Profile Cylinders

These single-acting, spring-return cylinders are designed for uses where high force and low overall height are requirements – the largest is only 2" high – making them ideal for clamping fixtures where space is limited. The crowned piston rods make them ideal for

powering toggle clamps, levers, and linkages, or for directly contacting and clamping the workpiece. Cylinder bodies are specially heat treated for exceptional wear and corrosion resistance. Each cylinder has a built-in heavy-duty spring for fast return, and case hardened piston for long service life. Also you may choose from base mounted or side mounted versions.

Cartridge Pull Cylinders

Hytec's "Pull" cylinders retract when

hydraulically pressurized. They were created to permit the user to design a cylinder into a fixture while maintaining the replaceability and long life of a heat treated, corrosion resistant cylinder body. Typical applications of these cylinders include installation behind fixture plates or buried in tombstones where they can supply clamping force without taking up valuable fixture space.

These pull cylinders were designed for cartridge mounting in a cavity supplied by the user. The required cavity is simply a cylindrical bore with a properly deburred pressure port intersecting it, providing the hydraulic fluid connection.

Paired with Uniforce® clamps, these cylinders will provide consistent clamping forces while taking a minimum of fixture space.

Block Style Cylinders

Hytec's block style cylinders are doubleacting only and do not contain return springs, making them perfect for applications where rapid positive return is essential or where both pushing and pulling forces are required.

Now, more applications are possible thanks to the new threaded piston rods. Hytec threaded inserts or any custom-designed attachments may be used.

The simplest to mount – from either top or bottom – these cylinders require only a flat surface with a bolt hole. A locating hole in the bottom can be used to prevent rotation when necessary.

Cylinder control can be simplified in certain applications by supplying one side of the cylinder with a constant air pressure source to supply the return force. The other port of the cylinder can then be pressurized and released as if it were single-acting.

NOTE: For longest service life, all single acting cylinder applications should be designed to use 75% (or less) of the available stroke.

Threaded Body Cylinders






Our most versatile cylinder style, these threaded body cylinders are single-acting, spring-return, and can be outfitted for a wide variety of applications. Available in either Unified National Coarse or Fine threads, they're ideal for manifold mounting, but can also be used for external plumbing connections when fitted with a feeder cap. Mounting brackets and jam nuts can be specified for added mounting versatility. The threaded

pistons will accept optional Hytec pointed or crowned threaded inserts, flat faced toggle pads, or you can custom design your own attachments. These cylinders should always be used with a threaded insert to prevent damage to the workpiece and the cylinder.

Features:

- Manifold or conventional mounting
- Heavy duty return springs
- Optional jam nuts, feeder caps and mounting brackets
- · Threaded, plated piston rod
- Fine or coarse threads
- "0" ring seal included
- 100% corrosion resistant
- Single-acting
- Power-Tech treated body for long wear and corrosion resistance

Note: See page 23 for threaded inserts.



Fine The	d. Body Cyls.	Coarse Th	nd. Body Cyls.	Speci	fication	s		Dime	nsions	(In Inch	es)						
Cat. No.	A Thread Size	Cat. No.	A Thread Size	*Force (Lbs.)		Eff. Area (Sq. in.)			С	D Thd. Depth	E Hex.	F	G Dia.	H Dia.	J Thread Size	K Radius	L Dia.
100156	½-20 UNF	100064	½-13 UNC	245	.250	.049	.012	1.636	1.568		.312		.399	.156	_	.375	.062
100157	72 ZO OIVI	100065	/2 10 ONO	243	.500	.040	.024	2.042	1.974		.012	.156	.000	.100		.070	.002
100159	%-18 UNF	100139	%-11 UNC	550	.250	.110	.027	1.655	1.625		.438	.130	.502	.250			.094
100166	/° 10 0141	100148	/» 11 ONO	330	.500	.110	.055	2.225	2.187	.438	.400		.502		10-32 UNF		.004
100167	%-16 UNF	100149	3/-10 UNC	750	.500	.150	.075	1.756	1.718	.400	.531		.615	.300	10 02 0141	_	.125
100171	74-10 OIVI	100153	/4-10 ONO	750	1.000	.130	.150	2.475	2.437		.551	.187	.013	.500			.125
100172	1-12 LINE	_		1535	.500	.307	.153	2.005	1.937	.500	.750	.107	.875	.500	5/6-24 UNF		.187
100173	1-12 UNF	_	_ _	1333	1.000	.507	.307	2.629	2.562	.500	.750		.073	.500	7/16-24 OIVI		.107

NOTE: * Based on 5,000 psi max. operating pressure.

SPX HYTEC_®

Threaded Body Cylinders




This is our highest capacity cylinder in the threaded body style. This premium grade cylinder includes a gland bearing, wiper seal, and extension style return spring. Its plated, threaded piston rod resists wear and corrosion and accepts Hytec threaded inserts or custom made attachments. The 100208 can be mounted by threading it into a tapped hole in the fixture or by inserting it into a drilled hole and locking it on both sides using two hex jam nuts (optional). This conventionally mounted 1" stroke, singleacting cylinder has a 1/8" NPT side port for making hydraulic connections. Like our smaller, threaded body cylinders, the 110132 is intended for manifold mounting and requires only a flat-bottom hole for

installation.

Features:

- Threaded body design
- Single-acting
- · Threaded, plated piston rod
- · Optional hex jam nut
- · Rod wiper seal in gland bearing
- Power-Tech™ treated body for long wear and corrosion resistance


Note: See page 23 for threaded inserts. See page 19 for jam nut.




Threaded Body Cylinders




Foot Mounting Bracket











	FOOT MOUNTING BRACKETS														
	Dimensions (In Inches)														
Cat.	Α	В	С	D	E	F	G	Н	J	_ K	L		М		
No.										Thread Size	Dia.	Dia.	Depth		
400000	1.875	1.750	.938	.625	.250	.455	1.312	.812	.350	½-13 UNC	.281	.410	.218		
400001	2.000	1.875	1.000	.023	.312	.562	1.625	.938	.312	%-11 UNC	.359	.504	.406		
400002	2.000	2.000	1.000	.656	.344	.687	1.687	1.062	.375	%-10 UNC	.422	.598	.343		
400003	2.500	2.500	1.250	.812	.375	.750	2.000	1.182	.575	1-12 UNF	.422	.590	.545		

	JAM NUT	S	
Cat.	Dimensions	(In Incl	nes)
No.	A Thread Size	B Hex.	C
10391	½-13UNC	.750	.312
10390	½-20UNF	.750	.312
10395	5⁄8-11UNC	.938	.375
10394	%-18UNF	.938	.375
10397	3/4-10UNC	1.125	.422
10396	¾-16UNF	1.125	.422
201029	1-12UNF	1.500	.562
216207	1 5/16-16UN	2.000	.719

			FEEDER	CAPS			
SAE Port	s	NPT Por	ts	D	imensions	(In Inche	s)
Cat. No.	A Thread Size	Cat. No.	A Thread Size	B Thread Size	C Hex.	D	E
100927		500097	1/8-NTPF	½-20UNF	0.750	1.200	0.437
100928		500100	/8 -14 F	½-13UNC	0.730	1.200	0.437
100929		500098		%-18UNF	0.875		
100930	⅓6-20UNF SAE-4	500101		%-11UNC	0.675		
100931		500099	1/4-NTPF	3/4-16UNF	1.000	1.390	0.500
100932		500102		3/4-10UNC	1.000		
100933		500103		1-12UNF	1.250		

NOTE: 5,000 psi max. operating pressure.



Center Hole Cylinders



Our center-hole cylinders can be used as single- or double-acting workholding devices.

Mounting can be done in any of several ways: use the thru-holes for mounting from the top, use the tapped holes in the bottom for mounting from underneath, or secure with a single stud or rod through the center. The pistons are threaded to accept the optional crowned threaded inserts, used when the cylinder contacts the work directly.

Features:

- · Single- or double-acting
- Multiple mounting options
- · Heavy-duty return spring

- Converts manual clamping to hydraulics
- · Plated, threaded piston rods

18,000 16,000 (14,000 29, 12,000 10,000 8000 4000 2000	Į,			
2000	Į.	 	 00.50	_


0 1,000 2,000 3,000 4,000 5,000 Hydraulic Pressure (PSI)


Performance

---- Cylinder Nos. 100934, 100935


- Cylinder Nos. 100136, 100137, 100938, 100939

- Cylinder Nos. 100940





100934, 100935, 100936, 100937, 100938, 100939



SAE Ports			Specification	ns		
Cat. No.	A Adv. Port Thd. Size	B Ret. Port Thd. Size	* Force (Lbs.)	Stroke (In.)	Extend ar Eff. Area (Sq. In.)	od Retract Oil Cap. (Cu. In.)
100934	Tild. Oize	Titu. Oize		.500		.663
100935	ł		6,630	1.000	1.326	1.326
100936	7/ - 00UNE	⁷ ∕16-20UNF		.500		1.074
100937	⁷ /₁6-20UNF SAE-4	SAE-4	10.705	1.000	2.147	2.147
100938	SAE-4		10,735	.500	2.147	1.074
100939]			1.000		2.147
100940		_	17,120	.375	** 3.424	** 1.284

Cat.	Dimension	s (In Inches)								
No.	С	D	E	F	G	Н	J	K	L	M
SAE Ports								Dia.	Thd. Size	Thd. Depth
100934	2 000	1.000	1.750	.562	1.812	.625	1.250			
100935	2.000	1.000	1.750	.562	1.012	.025	1.250			
100936								.322	3%-16UNC	.562
100937	2.550	1.275	2.188	.688	2.125	.875	1.750	.322	78-16UNC	.502
100938		1.2/5	2.100	.000	2.125	.875	1.750			
100939										
100940	_	-	-	.972	1.944	.972	1.944	-	1/4-20UNC	.312

Cat.	Dimensions	(In Inches)							
No.	N	0	Р	Q	R	S	Т	U	V
SAE Ports			Dia.		Piston Thd.	Thd. Size	Dia.	Dia.	Inside Dia.
100934	.938	1.000	2.812	3.203	1.000	5%-11UNC	.750	.516	.547
100935	1.438	1.500	2.012	4.203	1.000	78-110INC	.750	.510	.547
100936	1.000	1.094		3.304	1.188	³ ⁄ ₄ -10UNC		.781	.656
100937	1.500	1.594	3.500	4.304	1.100	/4-100NC	1.125	.761	.030
100938	1.000	1.094	3.300	3.304	1.375	⁷ ⁄8-9UNC	1.125	.906	.781
100939	1.500	1.594		4.304	1.373	78-90INC		.900	.761
100940	.756	-	3.370	3.140	1.275	1-8UNC	1.375	1.031	.875

Low Profile Cylinders






These single-acting, spring-return cylinders are designed for applications where high force and low overall height are requirements. Ideal for clamping fixtures where space is limited. The crowned piston makes them perfect for powering strap clamps, linkages or for direct contact with the workpiece. Cylinder bodies are heat treated using a special process for exceptional wear and corrosion resistance. Three sizes to choose from – the largest being only 2" high – with maximum forces ranging from 4,920 lbs. to 22,150 lbs. Each cylinder has a built-in heavy-duty spring for fast return, and case hardened piston for long service life.

The 100855 and 100925 use the same rugged design with different mounting

options. Designed for side mounting, four grade 8 mounting screws can easily resist the force of the clamp so no additional stops or clamp mounting structure is necessary.

Features:

- · Low overall height
- · Bronze plated piston
- · Piston rod wiper seal
- Heavy-duty return spring
- · Heat treated and plated cylinder body
- · Single-acting
- Power-Tech™ treated body for long wear and corrosion resistance



Ī	Cat. No. *F (L	Specifi	cations			Dimen	sions (In Inche	es)									
		*Force (Lbs.)	Stroke (ln.)	Eff. Area (Sq. In.)	Oil Cap.	Α	В	С	D	E	F	G	н	J	К	L	M - 1/4 NPTF .	N
	100855	4.920	.562	.994	.620	2.875	1.625	.812	.937	.625	.250	.281	¹ /4 NPTF	2.062	1.500	.282	-	-
	100925	4,320	.875	.554	.870	2.075	1.025	.012	.937	.023	.250	.201	/4 INF II	3.002	1.500	.202	¹ / ₄ NPTF	.550


NOTE: * Based on 5,000 psi max. operating pressure.

		Specifi	cations			Dimen	sions (l	n Inches)										
	Cat. No.	*Force (Lbs.)	(ln.)		Oil Cap. (Cu. In.)	A Dia.	В	C	D	E	F	G Dia.	Н	J	K Dia.	L Port Angle	M	N Thread Size	O Radius
1	00203	4,920	.562	.994	.62	2.562	1.635	1.667		.812	1.750	.625	1.000	.562	.219	0°	.770		1.150
1	00201	11,180	.437	2.236	1.00	3.250	2.190	1.750	.375	1.095	1.985	.750	1.312	.718	.281	5°	.630	1/4 NPTF	1.250
1	00202	22,150	.407	4.430	2.00	4.000	3.000	2.000		1.500	2.270	1.125	1.560	.968	.406		.000		1.280

NOTE: *Based on 5,000 psi max. operating pressure.

SPX HYTEC_®

Block Style Cylinders



Hyteo's block style cylinders are doubleacting only and do not contain return springs, making them perfect for applications where rapid positive return is essential or where both pushing and pulling forces are required.

Now, more applications are possible thanks to the new threaded piston rods. Hytec threaded inserts or any custom-designed attachments may be used.


The cylinders can be mounted from top or bottom using a single cap screw and either the thru-hole on the top or the tapped hole in the bottom. A locating hole in the bottom can be used to prevent rotation when necessary.


Cylinder control can be simplified in certain

applications by supplying one side of the cylinder with a constant air pressure source to supply the return force. The other port of the cylinder can then be pressurized and released as if it were single-acting.

Features:

- · Threaded, plated piston rod
- Double-acting
- Single screw mounting
- Piston threads withstand full retract forces. **Note:** See page 23 for threaded inserts.





	Spe	cifica	tions					Dime	nsion	s (In In	ches)										
Cat. No.	*Fo		Stroke (In.)	Eff. A		Oil C		A	В	С	D	E	F Thread Size	G Dia.	н	J	к	L Dia.	M Dia.	N	O Thread Size
	Adv.	Ret.		Adv.	Ret.		Ret.														
100055B	2210	1225	.500	.442	.245	.221	.123	2.312	2.500	1.500	1.844	.750	⁵ ⁄ ₁₆ - 24 UNF	.500	1.094	1.490	.500	.257	.257	.328	⁵ ⁄₁6- 18 UNC
100056B	2210	1225	1.000	.442	.245	.442	.245	2.812	2.500	1.500	1.844	.750	⁵ / ₁₆ - 24 UNF	.500	1.094	1.490	.500	.257	.257	.328	⁵ / ₁₆ - 18 UNC
100061B	7425	4415	.500	1.485	.883	.742	.442	2.812	3.000	2.500	1.938	1.250	⁵ ⁄₁6- 24 UNF	.875	1.344	2.094	.812	.312	.257	.328	³ / ₈ - 16 UNC
100062B	7425	4415	1.000	1.485	.883	1.485	.883	3.312	3.000	2.500	1.938	1.250	⁵ ⁄₁6- 24 UNF	.875	1.344	2.094	.812	.312	.257	.328	³ %- 16 UNC


	Dime	nsion	s (In In	ches)					
Cat. No.	P Min.	Q	R	s	Т	Advance Port Re Port NPTF N 1/6-	V Retract Port	W Thread Depth	X (REF)
100055B	.500	.375	1.000	.344	.344		½- NPTF	.438	2.23
100056B	.500	.375	1.500	.344	.344	½- NPTF	½- NPTF	.438	2.73
100061B	.625	.500	1.188	.500	.500	1/8- 1/8-		.438	2.76
100062B	.625	.500	1.688	.500	.500	½- NPTF	½- NPTF	.438	3.26

NOTE: * Based on 5,000 psi max. operating pressure


Cylinder Threaded Inserts




Pointed Threaded Insert (500161, 500164)



Toggle Pad Threaded Insert (500162, 500165)



Crowned Threaded Insert (500160, 500163, 201884)



	POINTED THREADED INSERTS													
Cat.	Dimensions (In Inches)													
No.	Used With Cat. No. A B C Hex.													
500161	100139, 100148, 100149, 100153, 100159, 100166, 100167, 100171	10-32 UNF	.630	.312	.250									
500164	100172, 100173, 100208, 100043B, 100044B, 100049B, 100050B, 100055B, 100056B, 100061B, 100062B	⁵ /16-24 UNF	.630	.375	.250									

	TOGGLE PAD THREA	DED INSERT	s										
Cat.	Dimensions (In Inches)												
No.	Used With Cat. No.	A Thread Size	В	C Hex.	D	E Dia.							
500162	100139, 100148, 100149, 100153, 100159, 100166, 100167, 100171	10-32 UNF	.812	.312	.438	.375							
500165	100172, 100173, 100208, 100043B, 100044B, 100049B, 100050B, 100055B, 100056B, 100061B, 100062B	5/16-24 UNF	1.156	.563	.750	.688							

	CROWNED THREADED INSERTS													
Cat.	Dimensions (In Inches)													
No.	Used With Cat. No.	A Thread Size	В	C Hex.	D	E Radius								
500160	100139, 100148, 100149, 100153, 100159, 100166, 100167, 100171	10-32 UNF	.480	.312	.100	.875								
500163	100172, 100173, 100208, 100043B, 100044B, 100049B, 100050B, 100055B, 100056B, 100061B, 100062B	5/16-24 UNF	.480	.375	.100	.875								
201884	100226, 100141, 100844, 100847, 100926	½-13 UNC	1.315	.750	.190	1.500								

Cartridge Pull Cylinders



These "Pull" cylinders retract when hydraulically pressurized. They were created to permit the user to design a cylinder into a fixture while maintaining the replaceability and long life of a heat treated, corrosion resistant cylinder body. Typical applications of these cylinders include installation behind fixture plates or buried in tombstones where they can supply clamping force without taking up valuable fixture space.


These pull cylinders were designed for cartridge mounting in a cavity supplied by the user. The required cavity is simply a cylindrical bore with a properly deburred pressure port intersecting it, providing the hydraulic fluid connection. They are for single acting systems only where the force

for cylinder return (extension) is supplied manually or through a spring designed into the application by the user. A return spring that can be built into the application is available.

(No. 251549 Order Separately)

Features:

- Compact design
- Manifold mounting eliminates tubing
- Threaded, plated piston rod
- Power-Tech™ treated body for long wear and corrosion resistance
- 5,000 psi maximum pressure rate
- Rod wiper to exclude contaminants
- Single-Acting




0-4	Specific	cations			Dime	nsions	(In Inch	ies)						
Cat. No.	*Force (Lbs.)	Stroke (in.)	Eff. Area (Sq. In.)	Oil Cap. (Cu. In.)	Α	В	С	D Dia.	E Dia.	F Dia.	G Threa	d	H Thread Size	J
											Size	Depth		
100866	5,215		1.043	.325	2.312	1.750	1.875	.750	1.125	2.000	3%-16 UNC	500		
100867	1,740	.312	.348	.108	1.902	1.500	_	.750		1.500	78-16 UNC	.500		
100880	5,215		1.043	.325	2.312	1.750	1.875	.750	1.125	2.000			½-13 UNC	.750


Note: * Based on 5,000 psi max. operating pressure.


Cartridge Pull Cylinder Installation




100866-100867-100880 **INSTALLATION IDEAS**











MOUNTING CAVITY



	Cavity Di	imensions						Oil Passage Location		
Cat. No.	A Dia.	B Cylinder Body Cavity	C Dia.	D Dia.	E Chfr. / Rad. Max.	†F	G	*H Min.	*J Max.	
100866	2.000 2.003	1.755 1.765	1.750 1.135					.485	1.020	
100867	1.500 1.503	1.500 1.510	1.250 .780	.744 .754	.065	.080 .100	.760 .790	.510	.970	
100880	2.000 2.003	1.755 1.765	1.750 1.135					.485	1.020	

^{*} Tolerance zone for blended oil passage hole. Tolerance zone does not allow any up and down motion of cylinder body. † Chamfer to be located at end of bore "A" from which the cylinder will be assembled.

Uniforce® Hydraulic Clamp



These clamps are a combination of Mitee-Bite® Products Uniforce® Clamp and Hytec's cartridge pull cylinders. Two pull cylinders are offered to power each of five of the most popular Uniforce clamps. One will create the force necessary to achieve the clamp's rated force at 5,000 psi hydraulic pressure. The other powers the clamp to its maximum rating at only 2,500 psi. This allows the efficient use of these clamps in lower pressure systems however, *never exceed the maximum pressure rating* of the clamp/cylinder assembly.

The pull cylinders are designed for cartridge mounting in a cavity supplied by the fixture builder. The required cavity is simply a cylindrical bore with a properly deburred pressure port intersecting it, providing the fluid connection. Where possible, pins inserted in the back of the piston are provided.


These pins can be guided by holes drilled in the sub-plate to prevent cylinder rotation when adjustments are made. A breather hole should always be provided and may be combined with the pin holes where appropriate.

An external stop prevents over-travel of the clamp if actuated without a workpiece in place.

Features:

- Minimal space requirements
- Reduces repetitive motion injuries
- 5,000 psi and 2,500 psi max. versions
- Cylinders require no additional fixture space
- Rod wiper excludes contaminants
- Plating & Power-Tech™ processes resist corrosion
- Single-acting, spring return

Mitee-Bite and Uniforce are registered trademarks of Mitee-Bite Products Company.




Clamp &		sembly Spec	cifications	Cylinder S	Specification	ıs	Cylinder D	Dimensions	(In Inches)			
Cylinder Assembly	Operating Pressure Max.	Holding Force Max. (Lbs.)	Clamp Spread Max.	Stroke (In.)	Eff. Area (Sq. in.)	Oil Cap. (Cu. in.)	Α	В	С	D	Piston	
Cat. No.	(psi)	, ,									Size	Depth
110059	5,000	290	.565	.123	.137	.017	1.115	1.210	.373	.810	8-32 UNC	.320
110060	2,500	290	.505	.120	.353	.043	1.113	1.210		1.185	0-32 0110	.320
110061	5,000	1,500	.830		.555	.063		1.325	.560	1.105	1/4-20 UNC	.375
110062	2,500	1,500	.030		.537	.096	1.240	1.417	.560	1.309	/4-20 UNC	.373
110063	5,000	2,000	1.120	.178	.557	.090		1.417		1.509	%-18 UNC	.470
110064	2,500	2,000	1.120		1.042	.185	1.365	1.470	.748	1.748	716- 10 OINC	.470
110065	5,000	2.500	1.650		1.042	.165	1.305	1.470	./46	1.748	½-13 UNC	.500
110066	2,500	3,500	1.050		1.802	.519	1.490	1.605	.873	2.123	/2-13 UNC	.500
110067	5,000	6 000	2.175	.288	1.002	.519	1.490	1.690	.0/3	2.123	%-11 UNC	.625
110068	2,500	6,000	2.1/5		3.542	1.020	1.615	2.000	1.059	2.873	78-11 UNC	.025

Clamp &	Uniforce (Clamp Dimer	nsions (In In	iches)					Uniforce
Cylinder Assembly Cat. No.	F	G	Н	J	Cap S	crew	L	M C'Bore	Clamp (only) Cat. No.
Cat. No.					Thd. Size	Length		Depth	Cat. No.
110059	.575	.220	.410	.485	8-32 UNC	.625	.625	.165	500184
110060	.575	.220	.+10	.400	0 02 0110	.020	.020	.100	300104
110061	.790	.375	.635	.735	1/4-20 UNC	.875	.940	.255	500185
110062	.790	.373	.033	./33	/4-20 ONC	.075	.540	.255	300103
110063	1.090	.500	.820	.980	%-18 UNC	1.250	1.250	.310	500186
110064	1.050	.500	.020	.900	716-10 UNC	1.230	1.250	.310	300100
110065	1.590	.750	1.215	1.470	%-13 UNC	2.000	1.875	.510	500187
110066	1.590	.750	1.213	1.470	/2-13 UNC	2.000	1.075	.510	300107
110067	2.090	1.000	1.625	1.960	%-11 UNC	2.500	2.500	.625	500188
110068	2.090	1.000	1.023	1.900	78-11 UNC	2.500	2.500	.023	300100

Uniforce® Clamp Installation






	Cavity Din	nensions (In	Inches)		Oil Passag	ge Location	Cavity Dimensions (in inches)				
Cat. No.	A Dia.	B Cyl. Body Length Max.	C Dia.	†D	E Min.	F Max.	G Min.	Н	J	K Dia.	*L Vent Dia. Min.
110059	.812 .815	1.120	.387 .577		.475	.728					
110060	1.187	1.130	.572		.427	.710					
110061	1.190		.911		.437	.787					
110062	1.312	1.245 1.255	.572		.476	.734	_	_	_	_	
110063	1.315		1.000	.125	.470	.734					.125
110064	1.750	1.370	.760	.145	.531	.819					.125
110065	1.753	1.380	1.437		.501	.010					
110066	2.125	1.495	.885			.943	.510	.550	1.100		
110067	2.128	1.505	1.812		.526	.545	.510	.550	1.100	.270 .280	
110068	2.875 2.878	1.620 1.630	1.074 2.500			1.001	.650	.785	1.570		

Note: * Cavity must be vented † Chamfer to be located at end of bore "A" from which the cylinder will be assembled.

500184 — 500188 Application Chart

	Dimensions (In	Inches)
Cat. No.	A Groove Width	B Workpiece Spacing
500184	.440	.500
500185	.665	.750
500186	.850	1.000
500187	1.245	1.500
500188	1.655	2.000

Note: Groove "A" is recommended to maintain clamp orientation.



Cartridge Pull Cylinders




These cylinders retract when hydraulically pressurized to exert a pulling force on clamping elements or mechanisms. For straight pull applications only, they allow the user to design a cylinder into a fixture while maintaining the replaceability and long life of a heat treated, corrosion resistant cylinder body. Designed for single-acting systems only, the cylinder's return spring is built into the piston and requires no additional fixture space.

The pull cylinders are designed for cartridge mounting in a cavity supplied by the fixture builder. The required cavity is simply a cylindrical bore with a properly deburred pressure port intersecting it, providing the fluid connection. The depth of the bore matches nominal plate thickness so the cylinder can be easily "sandwiched" between two plates if desired. Where possible, pins inserted in the back of the piston are provided. These pins are

guided by holes drilled in the sub-plate and will prevent cylinder rotation when adjustments are made. A breather hole should always be provided and may be combined with the pin holes where appropriate.

Features:

- Minimal space requirements
- 5,000 psi max.
- · Rod wiper excludes contaminants
- · Manifold mounting eliminates exposed tubing
- Plating & Power-Tech™ processes resist corrosion
- Single-acting, spring-return
- Return spring included
- Power-Tech™ treated body for long wear and corrosion resistance




	Specification	ns			Dimensions	(In Inches)				
Cat. No.	Force (Lbs.)	Stroke (In.)	Eff. Area (Sq. In.)	Oil Cap. (Cu. In.)	Α	В	С	D	E Piston Thread	
									Size	Depth
110069	685	.123	.137	.017	1.115	1.210	.373	.810	8-32 UNC	.320
*110070	1,765	.120	.353	.043	1.113	1.210		1.185	0-32 0110	.020
110071	1,705		.555	.063		1.325	.560	1.105	1/4-20 UNC	.375
*110072	2,685		.537	.096	1.240	1.417	.500	1.309	74-20 ONO	.070
110073	2,000	.178	.557	.090		1.417		1.509	5/6-18 UNC	.470
*110074	5,210		1.042	.185	1.365	1.470	.748	1.748	716-10 0110	.470
110075	5,210		1.042	.103	1.505	1.470	.740	1.740	½-13 UNC	.500
*110076	9,010		1.802	.519	1.490	1.605	.873	2.123	/2-13 ONO	.500
110077	3,010	.288	1.002	.519	1.490	1.690	.073	2.123	%-11 UNC	.625
*110078	17,710		3.542	1.020 1.615		2.000	1.059	2.873	/8-11 UNC	.025


^{*} Intended for lower pressure applications. Operation above 2,500 psi may limit the cycle life of the cylinder and attaching fastener.

Pull Cylinder Installation



110069 — **110078** Cavity Dimensions






Required thickness will vary due to fixture material used. Must resist maximum cylinder force.

Required thickness will vary due to fixture material used. Must resist maximum cylinder force.

	Cavity Din	nensions (In	Inches)		Oil Passag	ge Location	Cavity Din	nensions (In	Inches)		
Cat. No.	A Dia.	B Cyl. Body Cavity	C Dia.	†D	E Min.	F Max.	G Min.	Н	J	K Dia.	*L Vent Dia. Min.
110069	.812 .815	1.120	.387 .577		.475	.728					
110070	1.187	1.130	.572		.427	.710					
110071	1.190		.911		.437	.787					
110072	1.312	1.245 1.255	.572		.476	.734	_	_	_	_	
110073	1.315		1.000	.125	.470	.754					.125
110074	1.750	1.370	.760	.145	.531	.819					.125
110075	1.753	1.380	1.437		.551	.019					
110076	2.125	1.495	.885			.943	.510	.550	1.100		
110077	2.128	1.505	1.812		.526	.943	.510	.550	1.100	.270 .280	
110078	2.875 2.878	1.620 1.630	1.074 2.500			1.001	.650	.785	1.570		

† Chamfer to be located at end of bore "A" from which the cylinder will be assembled.

Tapered Screw Expanded Clamp




Machining and Installation


Expand clamp approximately .005 over relaxed diameter and machine to fit workpiece bore, either on lathe or mill.

If machining the clamp on a lathe use the nut provided, on the back of the clamp, to tighten the tapered screw. This nut is used only to machine the clamp.

Machine a pocket, in the fixture, for the close tolerance "E" dimension and drill and tap mounting holes per "H" column. Drill and tap a hole from the "I" column in the center of the pocket for the tapered screw.

A recessed dowel pin may be installed into the flange for additional rigidity if required.






Part Number	Model Number	Α	В	С	D	+.000 E002	F	G†	H*	I	J
110200	#0	.86	.63	.59	.23	1.170	.49	.28	6-32 on .825 BHC	8-32	.30
110201	#1	.98	.75	.59	.23	1.240	.56	.48	6-32 on .910 BHC	1/4-20	.50
110202	#2	.98	.75	.59	.23	1.476	.79	.53	6-32 on 1.140 BHC	5/16-18	.56
110203	#3	1.13	.88	.69	.25	1.968	1.06	.71	8-32 on 1.550 BHC	3/8-16	.71
110204	#4	1.25	1.0	.81	.25	2.205	1.39	.90	8-32 on 1.790 BHC	1/2-13	.71
110205	#5	1.56	1.25	1.06	.31	2.736	1.65	1.15	10-32 on 2.200 BHC	5/8-11	.79
110206	#6	1.56	1.25	1.06	.31	2.972	2.03	1.15	10-32 on 2.515 BHC	5/8-11	.79
110207	#7	1.79	1.48	1.27	.31	4.232	3.06	1.15	1/4-20 on 3.646 BHC	5/8-11	.79

G† - Minimum diameter the "F" dimension can be machined or turned down to.

H* - (3) Mounting Screws Included.


This product is a registered trademark of Mitee-Bite.



Uniforce® Hydraulic Clamp for a variety of fixturing applications









The Uniforce Hydraulic Clamp can be the foundation for clamping a wide variety of workpieces:

- A. For more than just rectangular workpieces, the Uniforce hydraulic clamp can be equally effective for clamping round workpieces.
- **B.** Often, a single Uniforce hydraulic clamp is all that is necessary to securely hold a workpiece. Or, several clamps can be positioned along the length of the part.
- C. The hydraulic actuation of this clamp requires no additional space. Fixture density is not compromised because the hydraulic pull cylinder is buried below the workpieces. The Uniforce clamping elements can be purchased as bar stock and then customized to meet special length requirements.
- D. Applications can include castings as well as bar-stock and extrusions. The clamp will accommodate slight imperfections and draft angles.
- E. Five clamp sizes, each available in two different pressure ratings are available to fit a wide range of workpiece proportions.
- F. The Uniforce Hydraulic Clamp can clamp two workpieces as easily as one. The same clamping force is exerted on workpiece whether clamping one or two.



В



C