>Bolting Systems®

PE60 SERIES PUMP

High Pressure Hydraulic Bolting Pump





ENGINEERED TO DELIVER RELIABILITY

Designed and Configured to Meet A Variety of Tough Bolting Applications.

The Bolting Systems PE60 Series Hydraulic Pump offers increased control technology, longer run-time, and "plug and play" accessory options. The PE60 Series pumps meet a wide array of high-pressure bolting tool applications where durability, speed and performance is required.

Designed for

Torquing applications where hydraulic wrenches need to be driven manually or through a continuous cycle operation. The Bolting Systems PE60 Series Hydraulic Pump delivers the performance needed to improve productivity while keeping safety in mind.

Value Delivered.

- Industry leading, field proven, Power Team Vanguard Pump technology
- Ergonomic remote pendant, large button design, requiring low finger depression force to operate, decreasing operator fatigue, IP55 rated
- "Plug and Play" field installable accessories
- User friendly LCD / Keypad interface to enable quick setup and maximize productivity
- Weather resistant shrouds for motor/electrical protection (IPX4)



Large easy-to-use control panel. LCD interface option with high visibility in bright light.





Standard Control Panel

LCD Control Panel


Industry Leading heavy-duty pump for bolting applications

- LCD Models provide a host of information including digital pressure visibility, torque, run-time data and diagnostics, along with full control at the shroud and pendant.
- Standard or Intelligent Autocycle technology options for fast bolt/nut rundown
- True unloading valve achieves greater pump efficiency, allowing higher flow at maximum pressure.
- Reservoir size options available, refer to pump configuration page.
- Lightweight and portable. Best performance-to-weight ratio of all Bolting Systems pumps.
- 12 ft / 3m remote motor control Pendant
- Available in common voltages
 110/115V 50/60 Hz
 220/230V 50/60 Hz
- Optional accessories available, easily field installable (see Accessories page)

PUMP TECHNOLOGY AT A GLANCE



TECHNICAL DIMENSIONS







PE602BE1P - 230VAC, 1-Tool





PE603BD1P - 115VAC, with LCD, 4-Tool





Technical Specifications

А		С	D	E	F	Max Pressure Output Bar (psi)	RPM	dBA at Idle and Max Press	Amp Draw at Max Pressure	**Oil Delivery - l/min (cu.in/min) @				Wt*
	В									7 Bar (100psi)	34 Bar (500psi)	345 Bar (5000 psi)	689 Bar (10000 psi)	kg (lbs)
	miliimetres (inches)				Dai (ps.)	11033	230v (115v)		(Soopsi)	(3000 psi)	(10000 psi)			
334 (16.17)	474 (18.68)	271 (10.65)	248 (9.75)	108 (4.25)	477 (18.79)	700 (10,000)	12,000	83 / 91	14A (28A)	11.5 (700)	7.8 (475)	1.2 (70)	1.0 (60)	31.5 (69.4)

^{*} Weight typical for PE601BA1P, including oil

^{**} Delivery values may differ depending upon valve configuration

CONFIGURATIONS

Model Numbers / Ordering Information

Order Number	Pump Description	Function Control	Valve	LCD Equipped	Auto- cycle Capable	Usable Oil Capacity Litres (US Gal)
PE601BA1P	PE60 115 VAC 50/60 Hz, Single Phase, 1-Tool, 1.5 Gal	Remote Pendant	1-Port / 1-Tool	No	No	4.8 (1.28)
PE601BC1P	PE60 115 VAC 50/60 Hz, Single Phase, 4-Tool, 1.5 Gal	Remote Pendant	4-Port / 4-Tool	No	No	4.8 (1.28)
PE603BB1P	PE60 115 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 1-Tool, 1.5 Gal	Remote Pendant	1-Port / 1-Tool	Yes	Yes	4.8 (1.28)
PE603BD1P	PE60 115 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 4-Tool, 1.5 Gal	Remote Pendant	4-Port / 4-Tool	Yes	Yes	4.8 (1.28)
PE601BA2P	PE60 115 VAC 50/60 Hz, Single Phase, 1-Tool, 2.5 Gal	Remote Pendant	1-Port / 1-Tool	No	No	8.7 (2.30)
PE601BC2P	PE60 115 VAC 50/60 Hz, Single Phase, 4-Tool, 2.5 Gal	Remote Pendant	4-Port / 4-Tool	No	No	8.7 (2.30)
PE603BB2P	PE60 115 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 1-Tool, 2.5 Gal	Remote Pendant	1-Port / 1-Tool	Yes	Yes	8.7 (2.30)
PE603BD2P	PE60 115 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 4-Tool, 2.5 Gal	Remote Pendant	4-Port / 4-Tool	Yes	Yes	8.7 (2.30)
PE602BE1P	PE60 230 VAC 50/60 Hz, Single Phase, 1-Tool, 1.5 Gal	Remote Pendant	1-Port / 1-Tool	No	No	4.8 (1.28)
PE602BG1P	PE60 230 VAC 50/60 Hz, Single Phase, 4-Tool, 1.5 Gal	Remote Pendant	4-Port / 4-Tool	No	No	4.8 (1.28)
PE604BF1P	PE60 230 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 1-Tool, 1.5 Gal	Remote Pendant	1-Port / 1-Tool	Yes	Yes	4.8 (1.28)
PE604BH1P	PE60 230 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 4-Tool, 1.5 Gal	Remote Pendant	4-Port / 4-Tool	Yes	Yes	4.8 (1.28)
PE602BE2P	PE60 230 VAC 50/60 Hz, Single Phase, 1-Tool, 2.5 Gal	Remote Pendant	1-Port / 1-Tool	No	No	8.7 (2.30)
PE602BG2P	PE60 230 VAC 50/60 Hz, Single Phase, 4-Tool, 2.5 Gal	Remote Pendant	4-Port / 4-Tool	No	No	8.7 (2.30)
PE604BF2P	PE60 230 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 1-Tool, 2.5 Gal	Remote Pendant	1-Port / 1-Tool	Yes	Yes	8.7 (2.30)
PE604BH2P	PE60 230 VAC 50/60 Hz, Single Phase, LCD-Autocycle, 4-Tool, 2.5 Gal	Remote Pendant	4-Port / 4-Tool	Yes	Yes	8.7 (2.30)

Roll Cage





"PLUG & PLAY" AFTERMARKET ACCESSORIES

Oil Cooler Kits

Order No.	Description
3001177	Oil Cooler kit designed for use with PE60 pumps with 115VAC Wt. 3.4kg (7.5lbs)
3001183	Oil Cooler kit designed for use with PE60 pumps with 230VAC Wt. 3.4kg (7.5lbs)

Order No.	Description					
3001185	Roll Cage for use with PE60 pumps Wt. 4.5kg (10lbs)					

>Bolting Systems®

CUSTOMER SERVICE CENTERS

Rockford, Illinois USA

5885 11th Street Rockford, IL 61109 USA Tel: +1 815 874 5556 Fax: +1 800 288 7031 info@spxboltingsystems.com

Gonzales, Louisiana USA

3141 S. Darla Avenue Gonzales, LA 70737 USA Tel: +1 225 774 0888 Fax: +1 225 450 2211 lousiana@spxboltingsystems.com

Houston, Texas USA

3106 E. Pasadena Frwy Pasadena, TX 77503 USA Tel: +1 713 472 2500 Fax: +1 713 472 2501 houston@spxboltingsystems.com

Corpus Christi, Texas USA

4930 Gemini Street
Corpus Christi, TX 78405 USA
Tel: +1 361 445 3727
Fax: +1 361 445 3728
corpus.christi.sc@spxboltingsystems.com

Distributed by:

Europe

Albert Thijsstraat 12 6471 WX Eygelshoven The Netherlands Tel: +31 45 567 8877 Fax: +31 45 567 8878 europe@spxboltingsystems.com

India

SPX Flow Technology (India) Pvt. Limited Survey No. 275 Odhav, Ahmedabad - 382 415 Tel: +91 99099 85454 Fax: +91 97277 19950 india@spxboltingsystems.com

Global Technical Bolting Support

boltingsupport@spxflow.com

South East Asia

20 Pioneer Crescent #06-01, West Park BizCentral Singapore 628555 Tel: +65 6265 3343 Fax: +65 6265 6646 singapore@spxboltingsystems.com

China

1568 Hua shan Road Shanghai, 200052 China Tel: +86 21 2208 5660 Fax: +86 21 2208 5682 china@spxboltingsystems.com

7F Treasury Building

Australia

SPX Flow Technology Australia Pty. Ltd. 211 Atlantic Drive Keysborough, Victoria, 3173 Tel: +61 02 9763 4900 Fax: +61 02 9763 7888 ft.aus.cs@spxflow.com

SPXFLOW[®]

SPX FLOW, Inc. reserves the right to incorporate our latest design and material changes without notice or obligation. Design features, materials of construction and dimensional data, as described in this bulletin, are provided for your information only and should not be relied upon unless confirmed in writing. Please contact your local sales representative for product availability in your region. The green ">" is a trademark of SPX FLOW, Inc.

For more information, visit www.spxflow.com.

