> Waukesha Cherry-Burrell®

UNIVERSAL 3 SERIES

Rotary Positive Displacement PumpsFront Loading Seal Design



SPXFLOW®

A NEW LEVEL OF SANITARY PERFORMANCE.



THE UNIVERSAL 3
SERIES of pumps is
the latest expression of
decades of continuing
product improvements.
They combine 3-way
mounting versatility
introduced by the
Universal 1 with new
features that extend pump
life and improve sanitary
performance.



Product features and benefits


Sanitary Features

- Front loading seal design
- CIP capable standard. Pump rotor has internal flats and will free drain with vertical ports.
- Cover is free draining in horizontal or vertical port positions.
- Rotor/shaft connection is completely sealed from product zone and reduces the risk of corrosion.
- Single mechanical seals standard. Optional double mechanical seals and o-ring seals also available. Ability to switch seal types without additional machining.
- Cover seal is a profile design to improve cleanability and resist particulates from being "pinched" and trapped.
- Stainless steel gear case standard.
- Aseptic and rectangular flange options available.
- Seal flush and steam-in-place optional.

Shown with standard stainless steel gearcase



Shown with standard flat body profile



LONG-LIFE ENGINEERED FEATURES.

TYPICAL APPLICATIONS



NUTRITION & HEALTH

Soups, Stews, Tomato Paste Vegetables, Dressings Chocolate, Fats & Oils Batters, Cream Fillings Brewery, Wort Soft/Fruit Drinks



DAIRY PROCESSING

Cream, Milk Cheese Curd & Whey Cottage Cheese Yogurt



PHARMACEUTICAL/COSMETICS

Pill Pastes Syrups, Extracts, Slurries Face Creams & Lotions Hair Styling Gels & Liquids Dyes & Alcohols



CHEMICAL/INDUSTRIAL

Solvents, Paints Fuels Resins, Polymers & Sludges Oil & Lubricants Soaps

Long-life Features


- Up to 500 psi (34.5 bar) pressure capability.
- Pumps rated to 300°F (149°C) as standard.
- Special rotor nut designed for extended service without loosening.
- No bearings in the product zone.
- New 17-4 shafts are shorter and are larger diameter than previous models.
- No bearings in the product zone.
 - Reduces overhung load which improves shaft alignment and decreases seal and bearing wear for extended seal life.
 - Improves shaft strength and stiffness helping to eliminate vibration
- Heavy duty stainless steel bearing frame standard.
- Double tapered roller bearings.
- Greased lubed bearings for positive lubrication to all bearings over entire speed, temperature and pressure range.
- Body retaining screws for maintaining mechanical seal contact during inspection.
- Extended outer seal life. A wave spring, instead of an o-ring, mechanically loads the seal.
- Unique mechanical seal design utilizes 2 pin stationary seal and special design shaft for rotary seal.

Installation Features

- Bidirectional flow. Rotors, locked with torqued nuts, rotate securely in either direction. No more flow direction/shaft position specifications.
- Versatile 3-Way mounting of gear case, including vertical alignment of ports.
- Upper or lower shaft position.
- Non-galling Waukesha "88" alloy rotors standard; permits running at tighter clearances and pumping a wide range of viscosities.
 - Stainless steel rotors also available.
- 316L stainless steel pump body and cover.
- Electro-polish of product contact surfaces, optional.

TIME-TESTED ROTARY PUMP; CIRCUMFERENTIAL-PISTON OPERATING PRINCIPLE

In the Waukesha Cherry-Burrell design, arc-shaped "pistons" (rotor wings) travel in annular-shaped cylinders machined in the pump body; the resulting long sealing path reduces slippage and produces a smooth flow of product without destructive pulses or pressure peaks and without valves or complex parts.




FOR LOW VISCOSITY FLUIDS

Rotors, made of Waukesha "88" alloy, can be run with close clearance to the 316L stainless steel fluid head, without galling or seizing should inadvertent pressure surges cause contact. The close clearances combined with the rotor geometry, which gives a long sealing path between the pump inlet and outlet, means low slip operation. As a result, you achieve: high efficiency, good priming ability, metering capability and good flow control.



The large fluid cavities of the rotors, plus the large easy entry anti-cavitation ports, allow efficient pumping of high viscosity fluids, slurries or even liquids with large chunks or particles.



FOR NON-LUBRICATING AND ABRASIVE FLUIDS

The Waukesha Cherry-Burrell design has no bearing in the fluid being pumped, no sliding or rolling contact and no rotor-to-rotor contact. This produces MAXIMUM SERVICE LIFE even under severe operating conditions.

Product Specifications

STANE	STANDARD U3 MODELS													
	DISPLACEMENT PER REVOLUTION	NOMINAL CAPACITY TO	INLET/ OUTLET	OPTIONAL INLET/ OUTLET	PRESSURE RANGE UP TO*	MAXIMUM RPM	APPROX SHIP WT.	TEMP RANGE						
006-U3	.0082 GAL. (.031 LITER)	8 GPM (1.8 m3/hr.)	1"	11/2"	300 PSI (20.7 BAR)	1000	56lb (25KG)							
015-U3	.0142 GAL. (.054 LITER)	11 GPM (2.5 m3/hr.)	11/2"	-	250 PSI (17.2 BAR)	800	56lb(25KG)							
018-U3	.029 GAL. (.110 LITER)	20 GPM (4.5 m3/hr.)	11/2"	2"	200 PSI (13.8 BAR)	700	65LB (30KG)							
030-U3	.060 GAL. (.227 LITER)	36 GPM (8.2 m3/hr.)	11/2"	2"	250 PSI (17.2 BAR)	600	130LB (59KG)							
040-U3	.076 GAL. (.288 LITER)	46 GPM (10.4 m3/hr.)	2"	-	150 PSI (10.5 BAR)	600	140LB (64KG)	Std Rotors:						
045-U3	.098 GAL. (.371 LITER)	58 GPM (13.2 m3/hr.)	2"	-	450 PSI (31.0 BAR)	600	295LB (134KG)	-40°F (-40°C)						
060-U3	.153 GAL. (.579 LITER)	90 GPM (20.4 m3/hr.)	21/2"	3"	300 PSI (20.7 BAR)	600	285lb (129KG)	to 300°F						
130-U3	.253 GAL. (.958 LITER)	150 GPM (34.1 m3/hr.)	3"	-	200 PSI (13.8 BAR)	600	305lb (138KG)	(149°C)						
180-U3	.380 GAL. (1.438 LITER)	230 GPM (52.2 m3/hr.)	3"	-	450 PSI (31.0 BAR)	600	520LB (236KG)							
210-U3	.502 GAL. (1.900 LITER)	300 GPM (68.1 m3/hr.)	4"	-	500 PSI (34.5 BAR)	600	915LB (415KG)							
220-U3	.521 GAL. (1.972 LITER)	310 GPM (70.4 m3/hr.)	4"	-	300 PSI (20.7 BAR)	600	590LB (268KG)							
320-U3	.752 GAL. (2.847 LITER)	450 GPM (102 m3/hr.)	6"	-	300 PSI (20.7 BAR)	600	895LB (406KG)							

RECTA	RECTANGULAR FLANGE U3 MODELS													
	DISPLACEMENT PER REVOLUTION	NOMINAL CAPACITY TO	INLET/ W X L (INCHES)	OUTLET	PRESSURE RANGE UP TO*	MAXIMUM RPM	APPROX SHIP WT.	TEMP RANGE						
014-U3	.0142 GAL. (.054 LITER)	5.68 GPM (1.3 m3/hr.)	1.44 X 4.94	11/2"	250 PSI (17.2 BAR)	400	62LB (28KG)							
034-U3	.060 GAL. (.227 LITER)	24 GPM (5.5 m3/hr.)	1.81 X 6.84	2"	250 PSI (17.2 BAR)	400	116LB (53KG)							
064-U3	.153 GAL. (.579 LITER)	61 GPM (13.9 m3/hr.)	2.44 X 9.0	21/2"	300 PSI (20.7 BAR)	400	292LB (132KG)	Std Rotors:						
134-U3	.253 GAL. (.958 LITER)	101 GPM (22.9 m3/hr.)	3.19 X 9.38	3"	200 PSI (13.8 BAR)	400	312LB (142KG)	-40°F (-40°C)						
184-U3	.380 GAL. (1.483 LITER)	152 GPM (34.5 m3/hr.)	3.28 X 11.25	3"	450 PSI (31.0 BAR)	400	518LB (235KG)	to 300°F						
214-U3	.502 GAL. (1.90 LITER)	200 GPM (45.4 m3/hr.)	3.45 X 12.70	4"	500 PSI (34.5 BAR)	400	754LB (342KG)	(149°C)						
224-U3	.521 GAL. (1.972 LITER)	208 GPM (47.2 m3/hr.)	4.06 X 11.25	4"	300 PSI (20.7 BAR)	400	559LB (254KG)							
324-U3	.752 GAL. (2.847 LITER)	300 GPM (68.1 m3/hr.)	4.25 X 12.70	6"	300 PSI (20.7 BAR)	400	833LB (378KG)							

PERFORMANCE AND LONG LIFE THROUGH DESIGN EXCELLENCE AND QUALITY CONSTRUCTION




Single Mechanical Seal*
Standard seal configuration:
silicon carbide rotary seal
face and carbon stationary
seal face. Alternate materials
available for abrasive service.



Double Concentric Mechanical Seal* Used with flushing fluid to cool, lubricate, flush away residue. Best arrangement for severe service.



Single and Double
O-ring Seal
Traditional general purpose seal. Low cost and easy to service. Suitable for low pressure applications.100 psi, 7 bar



The Waukesha Cherry-Burrell Universal 3 Series gives you...


High pressure capability, up to 500 psi/34.5 bar, for more demanding jobs.

Longer service life, resulting from a fresh engineering approach and durable high quality components.


The right seal, for countless applications, plus interchangeability when needed

Metal rotor: Waukesha "88" non-galling alloy, for close running clearance.

Design conforms, to 3-A, EHEDG



Standard & Options



Clamp Connections







Bevel Seat


DIN, SMS, RJT

Asenti

Ports

Standard: Sanitary clamp type connections. Available in a variety of styles including S-Line, I-Line and Q-Line.

Options: Bevel Seat, European Types; DIN, SMS, RJT, Aseptic Ports





Rotors

Standard: Twin Wing suitable for most applications.

Rotor Clearance

- Standard for most applications up to 300°F (149°C)
- Low viscosity clearance rotors optional for applications up to 200°F (93°C)
- Contact application engineering for other rotor clearance options





Shown with optional 3-wing cover nuts

Cover & Gearcase

Standard: Stainless steel 17-4 shafts, top shaft position, stainless steel bearing retainers, shaft completely sealed from product zone.

Options:

- Lower shaft position
- Bearing isolators
- Pedestal shims for side mounted pumps. Left hand shaft position is standard
- Right hand shaft is positioned on side mounted gearcase

O-rings


Standard: Fluoroelastomer FKM

Options: Fluoroelastomer (FKM), EPDM, Fluoroelastomer (FFKM)


Shaft Position

Standard: Top Shaft Position

Option: Lower Shaft Position



Top Shaft Position




Lower Shaft Position

Mounting

Standard: Flat plate, epoxy painted, with adjustable feet, SS coupling guard, and Lovejoy or Woods coupling.

Options:

- 304 SS unpolished plate base with adjustable feet
- Portable base with rubber wheels
- SS tubular bases



Optional Side Mount Gear Case for vertical fluid entry and free draining of body

Standard left hand shaft position shown (right hand optional)

Bases & Drives

Standard: Stainless steel tubular base with adjustable feet and stainless steel guard and coupling.

Options:


- 304 SS plate
- Flat epoxy plate
- Portable base

Tru-Fit®


Standard: Close coupled Tru-Fit® pump mounted on stainless steel base with stainless steel adapters.


Options:

- 304 SS polished plate base
- NEMA or IEC frames available. Right angle reducer also available for additional space savings
- 1/2 through 60 horsepower drive options available
- Horizontal or vertical porting



Dimensional Data







STANDARD U3 MODELS													
										F	? *		
		СР	•	L	0	PORT SIZE	U +.000 001	2X	U3	U1/U2	DIFF. BETWEEN U3 AND U1/U2 "R" DIM.		
006-U3	IN	12.42	7.61	10.04	4.21	1	0.88	6.97	3.23	2.79	0.4		
000-03	MM	315	193	255	107		22	177	82	71	11		
015-112	IN	12.69	7.61	10.04	4.21	1.5	0.88	6.97	3.23	2.79	0.4		
015-U3	MM	322	193	255	107		22	177	82	71	11		
018-U3	IN	13.35	7.61	10.28	4.21	1.5	0.88	7.09	3.47	3.02	0.5		
010-03	MM	339	193	261	107		22	180	88	77	11.1		
030-U3	IN	15.16	8.8	12.05	5.21	1.5	1.25	8.5	4.26	3.84	0.4		
	MM	385	224	306	132		32	216	108	98	10.2		
040-U3	IN	15.54	8.8	12.21	5.21	2	1.25	8.64	4.43	4	0.4		
	MM	395	224	310	132		32	219	113	102	10.5		
045-U3	IN	19.11	11	14.84	7.31	2"	1.63	10.75	4.72	4.73	SAME		
045-03	MM	485	279	377	186		41	273	120	120	SAME		
000 112	IN	19.66	11	15.13	7.31	2.5	1.63	10.75	5.01	5.01	SAME		
060-U3	MM	499	279	384	186		41	273	127	127	SAME		
130-U3	IN	20.68	11	15.76	7.31	3	1.63	10.75	5.64	5.65	SAME		
130-03	MM	525	279	400	186		41	273	143	144	SAME		
180-U3	IN	23.48	14.8	19.03	9.38	3	2	13.06	4.21	4.2	SAME		
180-03	MM	596	376	483	238		51	332	107	107	SAME		
010 112	IN	27.07	17.72	21.85	10.38	4	2.38	14.73	5.64	4.7	0.9		
210-U3	MM	688	450	555	264		60	374	143	119	24.3		
000 110	IN	24.22	14.8	18.49	9.38	4	2	13.25	4.45	4.44	CAME		
220-U3	MM	615	376	470	238		51	337	113	113	SAME		
200 110	IN	27.66	17.72	22.34	10.38	6.00	2.38	16	6.02	5.09	0.9		
320-U3	MM	703	450	567	264	150# FLG	60	406	153	129	23.9		

^{*&}quot;R" dimension shown for customers converting from a U1/U2 pump to a U3 pump. All other dimensions are the same between U1/U2/U3. NOTE: Dimension "2X" applies for Bevel Seat, "S"-Clamp, "Q"-Clamp, 15I and 14I fittings (except 320-U3).


NOTE: Dimensions are for guidance purposes only. Contact your SPX FLOW Representative if more detailed measurements are needed.


TRU-FIT U3 MODELS													
		A	С	F	н	M¹	PORT SIZE	N¹					
006-U3	IN	14.38	9.81	13.9	18	28.02	1	16.22					
006-03	MM	365	249	353	457	712		412					
015-U3	IN	14.38	9.81	13.9	18	28.29	1	16.22					
013-03	MM	365	249	353	457	719		412					
018-U3	IN	14.38	9.81	13.9	18	28.29	1.5	16.22					
010-03	MM	365	249	353	457	719		412					
030-U3	IN	14.38	11.03	16.1	20	34.24	1.5	19.68					
030-03	MM	365	280	409	508	870		500					
040-U3	IN	14.38	11.03	16.1	20	34.61	2	19.68					
	MM	365	280	409	508	879		500					
045-U3	IN	18.38	12.63	19.51	28	44.24	2	22.65					
043-03	MM	467	321	496	711	1124		575					
060-U3	IN	18.38	12.63	19.51	28	44.52	2.5	22.65					
000-03	MM	467	321	496	711	1131		575					
130-U3	IN	18.38	12.63	19.51	28	45.54	3	22.65					
130-03	MM	467	321	496	711	1157		575					
180-U3	IN	20.38	14.66	23.41	36	50.24	3	26.07					
100-03	MM	518	372	595	914	1276		662					
220-U3	IN	20.38	14.66	23.41	36	50.98	4	26.07					
220-03	MM	518	372	595	914	1295		662					





 $NOTE: Dimensions \ are \ for \ guidance \ purposes \ only. \ Contact \ your \ SPX \ FLOW \ Representative \ if \ more \ detailed \ measurements \ are \ needed.$





RECTA	RECTANGULAR FLANGE U3 MODELS																	
		АО	С	CA	СВ	сс	CD	CP1	FA	FB	НА	М	PA	РВ	РС	PD	х	2X
014-U3	IN	12.50	0.50	1.63	0.50	6.50	NA	14.51	2.63	7.50	0.41	0.38	1.53	4.77	0.55	1.37	3.63	7.11
014-03	MM	318	13	41	13	165	NA	369	67	191	10	10	39	121	14	35	92	181
034-U3	IN	12.75	0.56	1.88	0.63	10.75	NA	17.41	3.00	12.00	0.53	0.50	1.87	6.90	0.56	2.55	3.88	8.13
034-03	MM	324	14	48	16	273	NA	442	76	305	13	13	48	175	14	65	98	206
064-U3	IN	13.94	0.50	4.00	0.52	12.20	NA	21.91	5.00	13.23	0.53	0.48	2.53	9.09	1.24	2.07	4.94	10.31
004-03	MM	354	13	102	13	310	NA	557	127	336	13	12	64	231	31	53	125	262
134-U3	IN	13.94	0.78	3.00	0.63	14.00	NA	22.93	4.55	15.25	0.53	0.48	3.27	9.52	0.64	2.86	4.94	10.31
134-03	MM	354	20	76	16	356	NA	582	116	387	13	12	83	242	16	73	125	262
184-U3	IN	20.75	0.63	5.75	0.63	16.75	8.38	26.48	7.00	18.00	0.53	0.61	3.36	11.33	1.82	3.34	7.25	13.78
104-03	MM	527	16	146	16	425	213	673	178	457	13	15	85	288	46	85	184	350
214-U3	IN	35.94	0.75	7.50	0.75	16.50	8.25	29.06	9.00	18.00	0.69	1.00	3.55	12.80	2.73	2.60	8.81	17.46
214-03	MM	913	19	191	19	419	210	738	229	457	18	25	90	325	69	66	224	443
224-U3	IN	23.75	0.63	4.38	0.63	16.75	NA	27.22	5.63	18.00	0.53	0.50	4.17	11.36	0.73	3.32	6.25	12.88
224-03	MM	603	16	111	16	425	NA	691	143	457	13	13	106	289	18	84	159	327
204-112	IN	35.94	1.06	7.50	0.75	16.50	8.25	29.66	9.63	18.00	0.69	1.00	4.37	12.82	2.63	2.59	8.81	17.75
324-U3	MM	913	27	191	19	419	210	753	244	457	18	25	111	326	67	66	224	451

¹ Dimensions affected by motor frame size

> Waukesha Cherry-Burrell®

SPXFLOW[®]

SPX FLOW, Inc. reserves the right to incorporate our latest design and material changes without notice or obligation. Design features, materials of construction and dimensional data, as described in this bulletin, are provided for your information only and should not be relied upon unless confirmed in writing. Please contact your local sales representative for product availability in your region. The green """ is a trademark of SPX FLOW, Inc.

Version: 06/2022

For more information, visit www.spxflow.com.