

PowerMon Compact

ON-LINE ANALYSING UNIT

General

In process water and environmental monitoring higher energy costs and regulatory requirements make continuous quality controls essential. On-line measurements are necessary to identify immediately if limits are exceeded.


In the process control, our analytical equipment guarantees a reliable control, ensure consistent product quality, and contribute to the safety and efficiency.

Advantages

- High accuracy and repeatability
- Long product life
- Short response time
- Low reagent need
- Little space requirement
- Portable type as option
- Optional 2nd sample line

Application area

- Surface water control in rivers and lakes
- Ground water control
- Swimming pool quality control
- Water treatment plant control
- Sewage plant control
- Industrial water control(e.g. cooling water, boiler feed water)



PowerMon Compact analyzer plate

- 1. Photometer
- 2. Peristaltic pump
- 3. Sample valve
- 4. Sample detector
- 5. Drain valve
- 6. Reaction or sample heating
- 7. Calibration valve
- 8. Titration vessel

Only 1 or 2 sample lines are possible on the PowerMon Compact.

The PowerMon Compact has no own display. An optional external display can be connected for communication.

TECHNICAL DATA No. of measuring points: Kolorimeter/Silikometer/Ionometer: 6 - 15 min typically Cycle time: Titrometer: variable 2-fold 0/4...20 mA, zero selectable, maximum burden 500 Ohm, galvanically isolated, test voltage 1000 V AC. Connection: SPEEDCON M12 male 4-pin Signal output: 4 voltage-free normally open contacts are provided, max. load: 30 V DC 6 A; 60 V DC 0.6 A; 110 V DC 0.2 A; 250 V AC 6 A Connection: SPEEDCON M12 male 8-pin (optional) General alarm, Limit alarm signal: Voltage-free normally open contacts: Voltage-free normally open contact, max. load: 30 V DC 6 A; 60 V DC 0.6 A; 110 V DC 0.2 A; 250 V AC 6 A Signal input: Connection: SPEEDCON M12 female 8-pin (optional) Sample quantity: At least 1 - 3 I/h (depending on application), particle-free Max. sample feed pressure Unpressurized 15 - 45 °C (288 - 318 K) 1 - 45 °C (274 - 318 K) Sample temperature: with sample heating (option): Connection: Flexible tubing (PVC, PVDC, Viton, etc.) ID 1.5 - 3 mm Waste outlet: Unpressurized, flexible PVC tube ID 10 mm Ambient temperature: 15 - 35°C (288 - 308 K); even less with sample heating Rated voltages: 24 VDC (85 ... 264 VAC at 47 ... 63 Hz with external power supply) Mains connection: 4-pin M12 SPEEDCON female, A-coded Power requirement: max. 108 VA IP 54 (with housing only) IP 65 (optional) Protection: Device class: Class A (according to DIN EN 61326:2004) USB : For data download and software update LAN : Network connection Interfaces: Modem : Optional CAN bus : For connection of external sensors Dimensions $H \times W \times D$ Plate only 400 x 417 x 220 mm with housing: Required space with appended display, handles, cords and connections: 450 x 450 x 240 mm 450 x 550 x 250 mm 05 - 11 kg 18 - 25 kg

PowerMon Compact (plate only):

PowerMon Compact:
PowerMon Compact Portable (Alu):

All sizes and weights without reagents!

We reserve the right to make technical changes without notice.

In frame

with housing

Weight



09 - 16 kg



SPX Flow Technology Norderstedt GmbH - Werkstraße 4 - D-22844 Norderstedt Phone: +49 40 52202-0 Fax: +49 40 52202-444 E-Mail: branluebbe@spx.com

SPX reserves the right to incorporate our latest design and material changes without notice or obligations.

Design features, materials of construction and dimensional data, as described in this bulletin, are provided for your information only and should not be relied upon unless confirmed in writing. Please contact your local sales representative for product availability in your region. For more information visit www.spx.com.