

Where Ideas Meet Industry





## NETTCO i-Series Mixer Additional Options Available

Expanded to cover a wider range of applications

#### **Bung Adaptor**

Allows for mixing in drums by fitting securely into the opening of the lid without the need for clamps or support brackets.

- Attaches to base module
- For use on standard drum with a 2" NPT bung
- Stainless Steel construction to prevent corrosion



Bung Adaptor Assembly with Shaft



Bung Adaptor

# Sanitary Flange Mechanical Seal Assembly

Clamps to sanitary tank flanges for a simple, clean connection when a mechanical seal is required.

- Attaches to base module
- 3", 4", and 6" Sanitary Flange designs available
- Single dry-running mechanical seal good for 50 PSI (340kPa) tank pressure
- Stainless Steel construction to prevent corrosion



Sanitary Flange Mechanical Seal Assembly with Shaft



Mechanical Seal



Mechanical Seal Cutaway



#### Sanitary Flange Lip Seal

Clamps to sanitary tank flanges for a simple, clean connection when a low pressure sealing device is required.

- Attaches to base module
- 3", 4", and 6" Sanitary Flange designs available
- Food grade lip seal good for 25 PSI (170kPa) tank pressure
- Stainless Steel construction to prevent corrosion



Sanitary Flange Lip Seal Assembly with Shaft



Flange Lip Seal

### **Angle Riser**

Available on open tank units for off-center positioning of the mixer.

- For use with the Fixed-Mount Open Tank Module
- Available in both a 7° and 10° option
- May allow elimination of baffles



Angle Riser Assembly with Shaft



Angle Riser

#### **Air Motor Option**

Operates wherever compressed air is required or available.

- 3 sizes of Air motors available
- Safe for use in flammable or explosive environments
- Air control valve varies speed
- · Light weight design for easy handling
- Available for all mounting configurations



Your local contact:



Air Motor





LIGHTNIN, An SPX Brand

135 Mt. Read Blvd., Rochester, NY 14611

Phone: (888) 649-2378 (MIX-BEST), (U.S. and Canada) or +1 (585) 436-5550

E-mail: LIGHTNIN@spx.com

For more information about our worldwide locations, approvals, certifications, and local representatives, please visit www. lightninmixers.com.

SPX Corporation reserves the right to incorporate our latest design and material changes without notice or obligation.

Design features, materials of construction and dimensional data, as described in this bulletin, are provided for your information only and should not be relied upon unless confirmed in writing.

Issued: 3/2010 B-935 Addendum



Global Headquarters 13515 Ballantyne Corporate Place Charlotte, North Carolina 28277 United States **Where Ideas Meet Industry** 

Where Ideas Meet Industry

www.spx.com