

Pumps in Action

Mozzarella Cheese

Issued By: Jeff Sporer, Technical Sales Director

Date: January 18, 2018

Bulletin No: FB-0504

Waukesha Cherry-Burrell*

Pump:

Waukesha Cherry Burrell - Model 130 Universal Twin Screw (UTS) Series

Industry:

Dairy

Challenge:

Pump an elastic/stretchy type of processed mozzarella pizza cheese without breaking the elasticity before packing

Solution:

The customer partnered with SPX FLOW to install a Waukesha Universal Twin Screw (UTS) model UTS-130 pump.

The Twin Screw pump successfully pumped the cheese and did not break the elasticity of the product. The pump was intentionally over-sized to keep the processing speed low and avoid water separation (running at less than 400 RPM).

To learn more about Waukesha Twin Screw Pumps, <u>click here</u> to view the animation or contact your SPX FLOW <u>Authorized Distributor</u> or <u>Sales Representative</u>.

